

## Allens Leak Detector Concentrate

### PRODUCT DESCRIPTION

Allens Leak Detector Concentrate is a concentrated blend of high foaming surfactants. Specially formulated to be completely biodegradable and non-corrosive to all types of pipe media. Readily diluted for use. Can be used in a variety of applicators and to refill Allens Leak Detector Pre-diluted 1 Litre Bottle.

### PRODUCT INFORMATION

- ◆ Contains a blend of anionic and non-ionic surfactants
- ◆ Incorporates a non aggressive complex detergent formulation
- ◆ A readily biodegradable, mild formula with neutral pH
- ◆ Convenient pack size
- ◆ Suitable for all leak detection operations
- ⇒ Ensures effective detection of gas leaks by readily forming bubbles at the area of leak
- ⇒ Suitable for use on all surface types including soft metals and plastics
- ⇒ Safe to use
- ⇒ One pack will dilute with the addition of water to make up 1 Litre RTU
- ⇒ *Excess Leak Detector Fluid can easily and safely be washed away*

### SPECIFICATION

Appearance	Slightly viscous liquid
Colour	Clear colourless/straw coloured
Odour	Slight detergent
pH	6-7
Specific Gravity @ 20°C	1.02 ± 0.01

### PACK SIZES

Available in 125 ml clear recyclable HDPE containers.

### DIRECTIONS FOR USE

Fill an empty 1 Litre Allens Leak Detector Fluid bottle with clean water to the fill level denoted by the red line. Add contents of Allens Leak Detector Concentrate into the 1 Litre bottle and invert a number of times to ensure thorough mixing prior to use. Apply product to area to be tested for leaks covering the whole of the suspect area. Any leaks will soon become obvious by the formation of bubbles at the point of the leak. Once testing is complete, Allens Leak Detector Fluid may be wiped away with a damp cloth leaving the area clean and uncontaminated.

Store in original container in a cool area.

For further information see product safety data sheet

#### Delf (UK) Ltd.

462 Cleveland Street, Birkenhead, Wirral, CH41 8EQ  
Tel:(0044) 151 652 4877 Fax: (0044) 151 652 3800  
Web: [www.delf-uk.com](http://www.delf-uk.com) E-mail: [info@delf-uk.com](mailto:info@delf-uk.com)